

1303 EAST DIVISION AVE.

LIGHT & WATER OF PARPORT

OFF OF BARRON.

Telephone (715) 537-3855

January 22,2001

Jim Loock, Chief Electric Engineer Public Service Commission 610 N. Whitney Way P.O. Box 7854 Madison, WI 53707-7854

RE:

In the Matter of Filing Plans for Appropriate Inspection and

Maintenance, PSC Rule 113.0607.

Dear Mr. Loock:

Enclosed for filing are 3 copies of Barron Light and Water's Preventative Maintenance Plan detailing inspection maintenance schedules, condition rating criteria, corrective action schedules, record keeping procedures and report filing schedules as documented in this rule.

Very truly yours,

Alan Junkers

Utility Manager

Barron Light and Water

Enclosures

RECEIVED

MM 15 200

Electric Division

PREVENTATIVE MAINTENANCE PLAN

Barron Light and Water

FILING DEADLINE FEBRUARY 1, 2001

January 22, 2001

Alan Junkers
1303 East Division
Barron, Wisc. 54812
715-537-3855
blwd@chibardun.net

TABLE OF CONTENTS

*		Page
I.	Preventative Maintenance Plan	2
II.	Inspection Schedule and Methods	2
III.	Condition Rating Criteria	3
IV.	Corrective Action Schedule	4
V.	Record Keeping	4
VI.	Reporting Requirements	4
VII.	Distribution – overhead inspection guide	5
VIII.	Distribution - underground inspection guide	8
IX.	Substation - Monthly inspection guide	10
X.	Substation – Annual Inspection Guide	18
XI.	Transmission – Annual Inspection Guide	20
XII.	Transmission – 5 Year Inspection Guide	21
	FORMS	
OVE	RHEAD DISTRIBUTION INSPECTION FORM	7
UND	DERGROUND DISTRIBUTION INSPECTION FORM	9
MON	NTHLY SUBSTATION INSPECTION FORM	13 – 17
ANN	TUAL SUBSTATION INSPECTION FORM	19
ΔΝΝ	IIIAL TRANSMISSION INSPECTION FORM	22

I. Preventative Maintenance Plan

The PSC 113.0607 rule reads;

Appropriate inspection and maintenance: system reliability.

- (1) PREVENTATIVE MAINTENANCE PLAN. Each utility or other person subject to this chapter, including persons who own electric generating facilities in this state who provide service to utilities with contracts of five years or more, shall develop and have in place its own preventative maintenance plan. This section is applicable to electric generating facilities as set forth at s. 194.491(5)(a)(1), Stats. Each plan shall include, among other things, appropriate inspection, maintenance and replacement cycles where applicable for overhead and underground distribution plant, transmission, generation¹, and substation facilities.
- (2) CONTENTS OF THE PLAN. (a) *Performance standard*. The Preventative Maintenance Plan shall be designed to ensure high quality, safe, and reliable service, considering: cost, geography, weather, applicable codes, national electric industry practices, sound engineering judgment and experience.
- 1 PSC staff interpretation is that generation applies to individual generators equal to or greater than 50 MW.

II. Inspection Schedule and Methods:

The purpose of this plan is to maintain or improve the electrical system reliability with the objective of increased municipal loyalty and satisfaction from our constituents. The goals are to meet and exceed the schedules established in this plan.

Exception reporting (inspected equipment not in good condition) will be the method of documentation on all inspection forms.

The scope of this plan is traditional and uses proven maintenance techniques. Unique operating and maintenance philosophies have not been considered. Also, manufacturer defects will be dealt with as they are communicated to this utility.

EVERY

SCHEDULE:	MONTHLY	ANNUAL	5 YEARS
Transmission (□69Kv and above)		X	X
Substations	X	X	
Distribution (OH & UG)			X

The inspection of Distribution facilities will be by individual substation circuits on a 5-year cycle such that the entire system will be inspected every 5 years. Inspector instructions for inspecting all facilities and forms are included with the plan.

METHODS: Five criteria groups will be used to complete the inspection of all facilities.

- 1. <u>IR</u> infrared thermography used to find poor electrical connections and/or oil flow problems in equipment.
- 2. <u>RFI</u> Radio Frequency Interference, a byproduct of loose hardware and connections, is checked using an AM radio receiver.
- 3. <u>SI</u> structural integrity of all supporting hardware including poles, crossarms, insulators, structures, bases, foundations, buildings, etc.
- 4. <u>Clearance</u> refers to proper spacing of conductors from objects, trees and other utility cables.
- 5. <u>EC</u> equipment condition on non-structural components such as circuit breakers, transformers, regulators, reclosers, relays, batteries, capacitors, etc.

III. Condition Rating Criteria:

This criterion, as listed below, establishes the condition of a facility and also determines the repair schedule to correct deficiencies.

- 0) Good condition
- 1) Good condition but aging
- 2) Non-critical maintenance required normally repair within 12 months
- 3) Priority maintenance required normally repair within 90 days
- 4) Urgent maintenance required report immediately to the utility and repair normally within 1 week

IV. Corrective Action Schedule

The rating criteria as listed above determine the corrective action schedule.

V. Record Keeping

All inspection forms and records will be retained for a minimum of 10 years. The inspection form contains all of the required critical information i.e. inspection dates, condition rating, schedule for repair and date of repair completion.

VI. Reporting Requirements

A report and summary of this plan's progress will be submitted every two years with the first report due to the Commission by February 1, 2003. The report will consist of a letter documenting the percent of inspections achieved compared to the schedule and a description of maintenance achieved within the scheduled time allowance.

VII DISTRIBUTION - OVERHEAD INSPECTION GUIDE

STRUCTURE

- Pole Condition
- Pole Leaning
- Crossarm Condition
- Insulators, Deadend, Pin
- Excess Fill or Soil Removal
- Pole Steps
- Grounds Intact
- Ground Molding
- Down Guys
- Guy Markers
- Guy Bonding/Insulator
- Signage Location Number, Warning Sign
- Customer Equipment
- Conductor
- Tie Wires
- U Guard/Conduit Condition

EQUIPMENT

- Transformers
 - ✓ Oil Leaks
 - ✓ Bushing Condition
 - ✓ Grounding/Bonding
- Capacitors
 - ✓ Fuses Blown
 - ✓ Bushing Condition
 - ✓ Oil Leaks
 - ✓ Tank Bulged
 - ✓ Switches, Oil, Vacuum
 - ✓ Control Conduit/Wiring
 - ✓ Grounding/Bonding
- Switches GOAB, Inline, Disconnect
 - ✓ Insulator Condition
 - ✓ Operating Handle/Locks
 - ✓ Linkage
 - ✓ Grounding/Bonding
 - ✓ Switch Number
- Cutouts
 - ✓ Insulator Condition
 - ✓ Fuse Size Tag

VII DISTRIBUTION - OVERHEAD INSPECTION GUIDE (con't)

EQUIPMENT (CON'T)

- "Arrestor
 - ✓ Insulator Condition
 - ✓ Connections
 - ✓ Ground Lead Disconnection
- Cable Terminators
 - ✓ Insulator Condition
 - ✓ Grounding/Bonding

CLEARANCES

- Ground Line
- Buildings, Bridges, Swimming Pool, Etc.
- Communications Facilities
- Fuel Tanks
- Other Electric Utilities
- Transmission Lines
- Over Streets, Roads, Alleys, Highways
- Tree Trimming
 - ✓ Clearance From Line
 - ✓ Vines on Poles
 - ✓ Danger Trees

INFRARED SCAN

- Main Three-Phase Feeders
- Priority Overhead Transformer Banks
 - ✓ Bushing Connectors Primary
 - ✓ Bushing Connectors Secondary
 - ✓ General Tank Heating
- Current & Voltage Transformers if Applicable

RFI CHECK

• OH system with AM radio as each circuit is inspected

	Γ	Т	T	T:	T	T	T	Τ	T	Τ	T	Т	T	Τ-	T			70
																LOCATION	MAP AREA	OVERHEAD DISTRIBUTION INSPECTION FORM
								<u> </u>			<u> </u>	<u> </u>	<u> </u>				ļ	ㅁ
	<u> </u>		<u> </u>	<u> </u>								<u> </u>	<u> </u>			Pole Condition/Leaning		ST
		<u> </u>		<u> </u>	<u> </u>			_	1			Crossarm Condition		고				
						<u> </u>		<u> </u>			<u> </u>	<u> </u>	<u> </u>	<u> </u>		Insulators, DE, Pin		B
						1	<u> </u>		<u>L</u>		<u> </u>	<u> </u>				Soil Conditions		
		<u> </u>				<u> </u>		<u> </u>			<u> </u>	ļ		<u> </u>		Pole Steps	SI	∣⊡
	<u> </u>			<u> </u>						<u> </u>	<u> </u>	<u> </u>	<u> </u>		<u> </u>	Grounds Intact, Molding	짇	Z
	<u> </u>			<u> </u>					<u> </u>	<u> </u>				<u> </u>		Down Guys and Markers	STRUCTURE	Z
				<u> </u>				<u> </u>		<u> </u>	<u> </u>	ļ		<u> </u>	<u> </u>	Guy Bond, Insulator	둤	꿈
				<u> </u>												Signs, Loc#, Warning	т	
													<u> </u>	<u> </u>		Customer Equipment		当
<u> </u>			<u> </u>			L		<u> </u>								Conductor and Ties		Q
																U'Guard/Conduit Cond		
													<u> </u>			RFI Check		Ö
												<u> </u>	<u> </u>	<u> </u>		Transformer	_	2
												l	<u> </u>	<u> </u>	L.	Switches	EQUIPMENT	≤
																Cutouts	₩	
																Arresters	₹	
						<u> </u>										Terminators	Z	
																Street Light		
																Tree Trimming	C	Date
																Ground Line Clearances	Ü	ਨ
																Building Clearances	CLEARANCE	
				<u> </u>												Streets, Roads, Alleys	NC	
L																Communication Clearance	111	l '_
																Rating Criteria O) Good Condition 1) Good Condition but aging 2) Non-critical Maintenance Required 3) Priority Maintenance Required 4) Urgent Maintenace Required	COMMENTS	Inspected bySub
																Date Item Corrected		Ckt
																Corrected By		1

_

VIII DISTRIBUTION - UNDERGROUND INSPECTION GUIDE

STRUCTURAL (Exterior & Interior) Transformer, Primary Pedestal, Secondary Pedestal, Switchgear.

- Enclosure Condition
- Level/Leaning
- Security
- Grade/Accessibility (Shrubs, Customer Facilities, Fill/Excavation)
- Numbering
- Voids/Gaps
- Signage Location Number, Warning Sign
- Pad/Vault Condition

EQUIPMENT

- Transformers
 - ✓ Oil Leaks
 - ✓ Bushing Condition
 - √ Grounding/Bonding
 - ✓ Elbows
 - ✓ Arrestors
 - ✓ Feed-Through
 - ✓ Cable Condition
 - ✓ Secondary Connections
- Primary Pedestals
 - ✓ Elbows
 - ✓ Junction Condition
 - ✓ Grounding/Bonding
- Secondary Pedestals
 - ✓ Secondary Connections
- Switches URD Switchgear
 - ✓ Insulator Condition
 - ✓ Operating Handle Security
 - ✓ Linkage
 - ✓ Grounding/Bonding
 - ✓ Switch Number/Fuse Size & Number

INFRARED SCAN and RFI CHECK

- Main Three-Phase Feeders (Risers & Switchgear)
- Priority URD Transformer Banks
 - ✓ Bushing Connectors Primary
 - ✓ Bushing Connectors Secondary
 - ✓ General Tank Heating

			Corrected By											
. t.			Date Item Corrected											
Sub Circuit		COMMENTS	Rating Criteria 0) Good Condition 1) Good Condition 2) Non-critical Maintenance Required 3) Priority Maintenance Required 4) Urgent Maintenace Required											
by	.	IN / RFI Scan	Priority URD Transformers, Bushings and											
Inspected by	0	ב ב	Main Three Phase Feeders, Risers & Switchgeat											
dsul			Switches, Signage, Insulators, Security, Linkage, Ground, Bonds											
	FNT		Secondary Pedestals, Connections							1	T	+	\dagger	
ي	FOLIPMENT		Primary Pedestals, Elbows, Grounding, Bonds, Junction cond.											
RM Date		-	Transformers, Leaks, Bushings, Cond, Connections											
N F0			Pad / Vault Condition											1
TIOI		L	Signage								T			
PEC	l W	L	Voids / Gaps								T			1
NZ Z	CTUR		Митьеппд											
TIOL	STRUCTURE		Grade / Accessibility											1
RIBU			Security											
IST			Level / Leaning											1
			Enclosure Condition											
UNDERGROUND DISTRIBUTION INSPECTION FORM	MAP AREA		EQUIPMENT											

IX SUBSTATION - MONTHLY INSPECTION GUIDE

TRANSFORMER MAIN TANK:

- Oil in bushings
- Bushing and arrestor porcelain
 - Cracks or chips
 - ✓ Rust or dirt
- Oil leaks
 - ✓ Main tank
 - ✓ Sample valves
 - ✓ Radiators
- Radiator bank
 - warm on top, cool at bottom
- Tank pressure
- Tank oil level
- Temperature gauge
- Cooling fans

TRANSFORMER LTC or VOLTAGE REGULATORS:

- Tank oil level
- "Drag hand positions
- Cabinet light
- Operation count
- Tank pressure
- Cabinet heater
- Cabinet contamination

TRANSMISSION CIRCUIT BREAKERS:

- OPEN/CLOSED indicator
- CHARGED/DISCHARGED indicator
- Cabinet light
- Cabinet heater
- Operations counter
- Bushings and supports
 - ✓ Cracks or chips
 - ✓ Rust or dirt
- Line and load side disconnect switches
 - ✓ Properly labeled
 - ✓ Aligned properly
- Handles grounded
- Emergency trip button
- Air / Oil compressors
- Air / Oil pressure gauge
- Spring operated mechanism
- Oil level gauge
- Tank oil leaks
- Reset switch
- Cabinet contamination
- Vents clean
- Gas pressures for GCBs

IX SUBSTATION - MONTHLY INSPECTION GUIDE (con't)

FEEDER CIRCUIT BREAKERS / RECLOSERS

- OPEN/CLOSED indicator
- CHARGED/DISCHARGED indicator
- Cabinet light
- Cabinet heater
- Operations counter
- Bushings and supports
 - ✓ Cracks or chips
 - ✓ Rust or dirt
- Line and load side disconnect switches
 - ✓ Labeled properly
 - ✓ Aligned properly
 - ✓ Handles grounded
- Emergency trip button
- Oil level gauge
- Tank oil leaks
- Reset switch
- Cabinet contamination
- Vents clean
- , , Gas pressures for GCBs

HIGH AND LOW VOLTAGE BUSS WORK:

- Bushing, insulator, arrestor, and support insulators
 - ✓ Chips or cracks
 - ✓ Rust or dirt
- Bird nests
- Potential transformers bushings
 - ✓ Cracks or chips
 - Rust or dirt
- Cable terminators
 - ✓ Leaking fluid
 - ✓ Cracks or chips

MANUAL SWITCHES:

- Properly labeled
- Ground connections
- Positioning and alignment
- Bushing and support insulators
 - ✓ Cracks or chips
 ✓ Rust or dirt

MOTOR OPERATED SWITCHES:

- OPEN/CLOSED indicator
- Properly labeled
- Cabinet heater
- Operations counter

IX SUBSTATION - MONTHLY INSPECTION GUIDE (con't)

CONTROL HOUSE/MISCELLANEOUS:

- Clock displays proper time
- AC/DC load center breakers
- Room temperature
- Rodents
- Panels labeled properly
- Panel lights
- Annunciator panel
- Panel meters
- SCADA system RTU
- SCADA alarms
- Position indicators agree
- Relay target information
- Emergency contact directory & dial tone for phone
- Safety Equipment

BATTERY:

- Liquid levels
- Proper float voltage on charger and battery
- Specific gravity in pilot cell
- Personal Protective Equipment
- Connection corrosion
- Leaking cells
- Dated solution in eyewash station

YARD AND FENCE:

- Fire extinguisher charged
- Fence ground connections
- Fence secured
- Security and emergency lights
- Site base and grade
- Standing water
- Warning signs

MONTHLY S	UBSTATION INSPECTIO)N FORM
INSPECTED BY:		
DATE:		
SUBSTATION:		
TRANSFORMER MAIN TANK	RATING: 0 1 2 3 4	(Circle One)
inspected X	COMMENTS	DATE CORRECTED CORRECTED BY
Oil in Bushings		
Bushing and Arrestor		
Oil Leaks		
Main Tank	, , , , , , , , , , , , , , , , , , , ,	
Sample Valves	4 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	
Radiators		
Radiator Bank		
Tank Pressure		
Tank Oil Level	111111111111111111111111111111111111111	
Temperature Gauge		
Cooling Fans		
Cooling : a.r.		
TRANSFORMER LTC or VOLTAGE REGULATORS	RATING: 0 1 2 3 4	(Circle One)
Tank Oil Level		
Drag Hand Positions		
Cabinet Light		
Operation Count		
Tank Pressure		
Cabinet Heater		
Cabinet Contamination		

inspected X COMMENTS CORRECTED OPEN/CLOSED Indicator CHARGED/DISCHARGED Indicator Cabinet Light Cabinet Heater Operations Counter Bushings and Supports Line and Load Side Disconnect Switches Handles Grounded Emergency Trip Button Air Compressors - Air / Oil Air Pressure Gauge - Air / Oil Spring Operated Mechanism Oil Level Gauge Tank Oil Leaks Reset Switch Cabinet Contamination Vents Clean	
SUBSTATION:	
HIGH VOLTAGE CIRCUIT BREAKER / CIRCUIT SWITCHER	
CIRCUIT SWITCHER Inspected X COMMENTS DATE CORRECTED OPEN/CLOSED Indicator CHARGED/DISCHARGED Indicator Cabinet Light Cabinet Heater Operations Counter Bushings and Supports Line and Load Side Disconnect Switches Handles Grounded Emergency Trip Button Air Compressors - Air / Oil Air Pressure Gauge - Air / Oil Spring Operated Mechanism Oil Level Gauge Tank Oil Leaks Reset Switch Cabinet Contamination Vents Clean	·
CIRCUIT SWITCHER Inspected X COMMENTS DATE CORRECTED OPEN/CLOSED Indicator CHARGED/DISCHARGED Indicator Cabinet Light Cabinet Heater Operations Counter Bushings and Supports Line and Load Side Disconnect Switches Handles Grounded Emergency Trip Button Air Compressors - Air / Oil Air Pressure Gauge - Air / Oil Spring Operated Mechanism Oil Level Gauge Tank Oil Leaks Reset Switch Cabinet Contamination Vents Clean	
inspected X COMMENTS CORRECTED OPEN/CLOSED Indicator CHARGED/DISCHARGED Indicator Cabinet Light Cabinet Heater Operations Counter Bushings and Supports Line and Load Side Disconnect Switches Handles Grounded Emergency Trip Button Air Compressors - Air / Oil Air Pressure Gauge - Air / Oil Spring Operated Mechanism Oil Level Gauge Tank Oil Leaks Reset Switch Cabinet Contamination Vents Clean	
OPEN/CLOSED Indicator CHARGED/DISCHARGED Indicator Cabinet Light Cabinet Heater Operations Counter Bushings and Supports Line and Load Side Disconnect Switches Handles Grounded Emergency Trip Button Air Compressors - Air / Oil Air Pressure Gauge - Air / Oil Spring Operated Mechanism Oil Level Gauge Tank Oil Leaks Reset Switch Cabinet Contamination Vents Clean	RRECTED BY
Cabinet Light Cabinet Heater Operations Counter Bushings and Supports Line and Load Side Disconnect Switches Handles Grounded Emergency Trip Button Air Compressors - Air / Oil Air Pressure Gauge - Air / Oil Spring Operated Mechanism Oil Level Gauge Tank Oil Leaks Reset Switch Cabinet Contamination Vents Clean	
Cabinet Heater Operations Counter Bushings and Supports Line and Load Side Disconnect Switches Handles Grounded Emergency Trip Button Air Compressors - Air / Oil Air Pressure Gauge - Air / Oil Spring Operated Mechanism Oil Level Gauge Tank Oil Leaks Reset Switch Cabinet Contamination	
Operations Counter Bushings and Supports Line and Load Side Disconnect Switches Handles Grounded Emergency Trip Button Air Compressors - Air / Oil Air Pressure Gauge - Air / Oil Spring Operated Mechanism Oil Level Gauge Tank Oil Leaks Reset Switch Cabinet Contamination Vents Clean	
Bushings and Supports Line and Load Side Disconnect Switches Handles Grounded Emergency Trip Button Air Compressors - Air / Oil Air Pressure Gauge - Air / Oil Spring Operated Mechanism Oil Level Gauge Tank Oil Leaks Reset Switch Cabinet Contamination Vents Clean	
Line and Load Side Disconnect Switches Handles Grounded Emergency Trip Button Air Compressors - Air / Oil Air Pressure Gauge - Air / Oil Spring Operated Mechanism Oil Level Gauge Tank Oil Leaks Reset Switch Cabinet Contamination Vents Clean	
Handles Grounded Emergency Trip Button Air Compressors - Air / Oil Air Pressure Gauge - Air / Oil Spring Operated Mechanism Oil Level Gauge Tank Oil Leaks Reset Switch Cabinet Contamination Vents Clean	
Emergency Trip Button Air Compressors - Air / Oil Air Pressure Gauge - Air / Oil Spring Operated Mechanism Oil Level Gauge Tank Oil Leaks Reset Switch Cabinet Contamination Vents Clean	
Air Compressors - Air / Oil Air Pressure Gauge - Air / Oil Spring Operated Mechanism Oil Level Gauge Tank Oil Leaks Reset Switch Cabinet Contamination Vents Clean	
Air Pressure Gauge - Air / Oil Spring Operated Mechanism Oil Level Gauge Tank Oil Leaks Reset Switch Cabinet Contamination Vents Clean	
Spring Operated Mechanism Oil Level Gauge Tank Oil Leaks Reset Switch Cabinet Contamination Vents Clean	
Oil Level Gauge Tank Oil Leaks Reset Switch Cabinet Contamination Vents Clean	
Tank Oil Leaks Reset Switch Cabinet Contamination Vents Clean	
Reset Switch Cabinet Contamination Vents Clean	
Cabinet Contamination Vents Clean	
Vents Clean	
Gas Pressures for GCBs	

MONTHLY	SU	BSTATION INSPECTIO	N FORM	
INSPECTED BY:			it i Oitivi	
DATE:				
SUBSTATION:				
FEEDER CIRCUIT BREAKER / RECLOSER		RATING: 0 1 2 3 4	(Circle One)	
inspected	x	COMMENTS	DATE CORRECTED	CORRECTED
OPEN/CLOSED Indicator			- CONTROLED	
CHARGED/DISCHARGED Indicator				
Cabinet Light				· · · · · · · · · · · · · · · · · · ·
Cabinet Heater				
Operations Counter				
Bushings and Supports				
Line and Load Side Disconnect Switches				
Emergency Trip Button				
Oil Level Gauge				
Tank Oil Leaks				
Reset Switch				
Cabinet Contamination				
/ents Clean				
Sas Pressures for GCBs				
	\neg			
	\top			

MONTHLY SUB	STATIO	NI	NS	PE	CT	101	FORM	
INSPECTED BY:								
DATE:								
SUBSTATION:								
	N							
HIGH & LOW VOLTAGE BUSS WORK	RATING:	0	1	2	3	4	(Circle One)	
		COM	MEN	ITS			DATE	CORRECTED
inspected X							CORRECTED	BY
Bushing, Insulator, Arrestor, and Supports								
Bird Nests								
Transformer Bushings								
Cable Terminators								
							-	
								
MANUAL SWITCHES	RATING:	0	1	2	3	4	(Circle One)	
Properly Labeled								
Ground Connections								
Positioning and Alignment								
Bushings and Supports					 		 	
					 -			
							_	
MOTOR OPERATED SWITCHES	RATING:	0	1	2	3	4	(Circle One)	
OPEN/CLOSED Indicator								
Proper Labeling								
Cabinet Heater								
Operations Counter								
locking criteria								

MONTHLY	SU	BSTATI	<u> </u>	I IN	ISP	EC	TIO	N FORM	
INSPECTED BY:									
DATE:				<u> </u>					
SUBSTATION:									
CONTROL HOUSE/MISCELLANEOUS		RATING:	0	1	2	3	4	(Circle One)	
inspected	x		COI	MME	NTS			DATE CORRECTED	CORRECTED BY
Clock Displays Proper Time									
AC/DC Load Center Breakers									
Room Temperature									
Rodents									
Panels Labeled Properly									
Panel Lights									
Annunciator Panel									
Panel Meters									
SCADA System RTU									
SCADA Alarms									
Position Indicators Agree									
Relay Target Information									
Emergency Contact Directory & Dialtone for Phone									
Safety Equipment			•••						
BATTERY		RATING:	0	1	2	3	4	(Circle One)	
Liquid Levels									
Proper Float Voltage on Charger & Battery									
Specific Gravity in Pilot Cell									
Personal Protective Equipment									
Connection Corrosion									
Leaking Cells									
Dated Solution in Eyewash Station									····
YARD & FENCE		RATING:	0	1	2	3	4	(Circle One)	
Fire Extinguisher Charged									
Fence Ground Connections									
Fence Secured									
Security and Emergency Lights								` .	
Site Base and Grade									
Standing Water									
Morning Signs	ı							1	

X Substation - Annual Inspection Guide

- Check equipment for level
- Check condition of concrete pads
- Perform oil and DGA analysis
- Battery
 - ✓ Intercell strap resistance
 - ✓ Individual cell voltages
 - ✓ Cell specific gravity
- Nameplate legible
- Equipment paint condition
- Proper equipment ID labels
- IR / RFI scans and checks

ANNUAL SUBSTATION INSPECTION FORM

Date

	Transmission line BEI	Control house				Wilches	Cwitch				Feeder CBs / Reclosers	riigii voltage Breaker	Ligh Vollagoid	ITC or regulators	Transformer	EQUIPMENT LISTING		Date
															C	Check equipment for level		
									_	_					c	Check condition of concrete pads	9	
															P	Perform oil and DGA analysis	WBST/	nspe
The Company of the Co			í												jrε	attery checks - Intercell strap esistance, Individual cell voltages, ell specific gravity	SUBSTATION INSPECTION CRITERIA	Inspected by
					\perp	1									N	ameplate legible	TION	
		_		_		_	_					\perp			E	quipment paint condition	RITER	
		\downarrow					\perp								Pr	oper identification labels	Ã	
															IR	/ RFI scans and checks		
																Rating Criteria O) Good Condition 1) Good Condition but aging 2) Non-critical Maintenance Required 3) Priority Maintenance Required 4) Urgent Maintenace Required	COMMENTS	Substation
														D	ate		MAINT	
														Co	orro	e Item Corrected	MAINTENANCE	

XI TRANSMISSION - ANNUAL INSPECTION GUIDE

STRUCTURE

- Pole Condition
- Pole Leaning
- Crossarm Condition
- Insulators, Deadend, Pin
- Excess Fill or Soil Removal
- Pole Steps
- Grounds Intact
- Ground Molding
- Down Guys
- Guy Markers
- Guy Bonding/Insulator
- Signage Location Number, Warning Sign
- Customer Equipment
- Conductor
- Tie Wires

EQUIPMENT

- Switches GOAB, Disconnect
 - ✓ Insulator Condition
 - ✓ Operating Handle/Locks
 - ✓ Linkage
 - ✓ Grounding/Bonding
 - ✓ Switch Number
- Arrestor
 - ✓ Insulator Condition
 - ✓ Connections

CLEARANCES

- Ground Line
- Buildings, Bridges, Etc.
- Communications Facilities
- Fuel Tanks
- Other Electric Utilities
- Over Streets, Roads, Alleys, Highways
- Tree Trimming
 - ✓ Clearance From Line
 - ✓ Vines on Poles
 - ✓ Danger Trees

XI TRANSMISSION - ANNUAL INSPECTION GUIDE (con't)

RFI CHECK

- Splices
- Connectors
- Dead Ends
- Switches
- Structures

XII TRANSMISSION - 5 YEAR INSPECTION GUIDE

<u>IR SCAN</u>

- Splices
- Connectors
- Dead Ends ·
- Switches

2	
Inspected	-
Date	

Çĸŧ

gns

	Corrected																
	Date Item Co							•									
	Co		 _	_			 							\dashv	\dashv	-+	
COMMENTS	Rating Criteria 0) Good Condition 1) Good Condition but aging 2) Non-critical Maintenance Required 3) Priority Maintenance Required 4) Urgent Maintenace Required																
	Sommunication Clearance												_				\dashv
SCH	Streets, Roads, Alleys						 									_	
CLEARANCE	Building Clearances								_							_	_
OLE/	Ground Line Clearances							<u> </u>									_
	Tree Trimming																
MENT	Arresters																_
EQUIPMENT	Switches						 						_				
	KFI Check						 	_									
	Conductor and Ties									_							_
	Customer Equipment					_									_		
	Signs, Loc#, Warning					_							ļ	_			
ZE	Guy Bond, Insulator											_		_			_
STRUCTURE	Down Guys and Markers								_		_	_			_		
COC	Grounds Intact, Molding											<u> </u>	_	_	_		
STF	Pole Steps												ļ_				
	Soil Conditions					<u> </u>						_	<u> </u>		_		
	Insulators, DE, Pin									<u> </u>				<u> </u>	<u> </u>		_
	Crossarm Condition													_	<u> </u>		
	Pole Condition/Leaning										<u> </u>		_	<u> </u>	<u> </u>	_	
MAP AREA	LOCATION																